



# DURALEX

## PRODUCT INFORMATION SHEET

### RENOVATOR CEILING WHITE

#### DESCRIPTION

**Duralex Renovator Ceiling White** is a budget flat ideal for ceilings. Its flat finish minimises surface imperfections and is suitable for fast application by airless spray or roller.

#### USES

**Duralex Renovator Ceiling White** was specifically formulated for interior application to ceilings in bedrooms, lounge rooms, etc.

#### SURFACE PREPARATION

**BEFORE PAINTING:** Ensure surface is firm, properly prepared, thoroughly dry, dust free, clean and free of all foreign matter. If necessary, fill all nail holes, cracks, etc. with a suitable filler, sand smooth and dust down.

Efflorescence or mould on any surface must be treated first.

New Ceilings

Apply one coat of **Duralex Renovator Undercoat & Wallboard Sealer** followed by two coats of **Duralex Renovator Ceiling White**.

Previously Painted Surfaces

Before recoating previously painted surfaces, ensure that the surface is firm. Test at random for its ability to withstand extra coats. Simply cut a small cross (x) through the paint with a razor blade, then place a piece of sticky tape firmly over the cut. Hold the end of the tape then rip the tape off. If the tape pulls the surface away, the surface is unsound. Test different areas before deciding whether or not the surface coating should be removed.

Apply one coat of **Duralex Surface Binder** where necessary. Touch up any bare areas with **Duralex Renovator Undercoat & Wallboard Sealer**. Apply two coats of **Duralex Renovator Ceiling White**. Use **Duralex Bleed Seal** on any surface which is smoke or fat stained and allow to dry at least two hours before painting. Dry, brown water stains are to be sealed back with oil-based white Cement Sealer, otherwise the stain will carry through.

#### APPLICATION

**IMPORTANT:** Wet brush or roller in water and shake off excess prior to use, for a smoother, nib free job. Do not overspread. Stir contents thoroughly before and during use with a broad flat stirrer, using an upward lifting action.

To ensure best performance, do not use any additive not approved by Duralex.

Avoid excessive brushing or roller pressure and disturbing

freshly laid paint which has begun to dry.

Thinning with up to 10% water may be necessary during hot weather or when painting highly absorbent surfaces.

#### DRYING TIME

Normally dries in 20 minutes in dry, well ventilated areas and may be recoated after 2 hours. In damp or humid conditions drying time is lengthened – Remember ventilation is important.

#### WEATHER

Surface temperature must be above 10°C during application and drying time. **Duralex Renovator Flat** must be at least two hours dry before dew, fog or rain when used outside.

#### COVERAGE

A maximum coverage rate of 14 square metres per Litre per coat. This may fall below 10 square metres per Litre when painting corrugated, rough or absorbent surfaces.

#### CLEAN UP

Wash all equipment with clean water. Any dried spots may be removed using methylated spirits.

#### COLOURS

Available in White which is compatible with all major tinting systems. Use 50% of tint formula for pastel colours. Tinter, if added, should be shaken and stirred in thoroughly immediately after addition.

#### CAUTION

Allow adequate cross ventilation when painting indoors during and after use to dissipate water vapour.

#### SIZES

20, 10, 6, 4 Litre.

#### ENVIRONMENT

Low odour. Low V.O.C.

Environmentally friendly.

#### IMPORTANT

Keep out of reach of children. To avoid spoilage of paint keep container sealed when not in use. Poison Information Centre (13 11 26).



The information given herein is believed to be accurate and reliable but is presented without guarantee, warranty or responsibility of any kind. Users of our products should perform their own tests to determine the suitability of each Duralex product for their particular purposes. This information is being constantly updated and subject to change without notice.

CDR-4-058

**DURALEX**  
ENVIRONMENTALLY  
AWARE

Page 1 of 2

3-5 Muriel Avenue, Rydalmere N.S.W. 2116  
**PHONE: (02) 9638 0568 FAX: (02) 9684 1864**

[www.duralexpaints.com.au](http://www.duralexpaints.com.au)

8/4/14

Once printed, this document is uncontrolled.

# **NEVER POUR LEFTOVER PAINTS DOWN THE DRAIN**

## **CLEANING UP AFTER PAINTING**

**(Industry standard for Water-based paint)**

### **EXCESS/UNWANTED PAINT**

- At the completion of a painting job, pour, brush or roll excess unwanted paint onto an absorbent material such as kitty litter, old rags, newspaper, cardboard, etc.
- Allow paint to dry, this could take up one week, then dispose with household waste collection services.

### **WASHING OF EQUIPMENT: (Two-Container Method)**

- **20 Litre containers are best!**
- Wash brushes, rollers and other equipment in the **FIRST** container of water.
- Transfer the washed equipment to the **SECOND** container filled with clean water for a final rinse.
- Allow the containers to stand, overnight the paint solids will settle to the bottom, this usually takes about 12 hours. The clear water from the **FIRST** container may now be poured on the garden where it will be absorbed into the ground. Avoid areas near drains, streams, rivers or lakes.

### **DISPOSAL OF RESIDUE:**

- Paint solids at the bottom of the first container can be scraped onto an absorbent material as previously described. Allow to dry, then dispose as previously described.
- The **SECOND** container can now be used as the first wash. Follow this cleaning system until the job is completed.

### **CAUTION:**

- Never allow waste water to enter household storm water drains or sewers.

## **DISPOSAL OF LEFTOVER PAINT CONTAINERS**

### **EMPTY OUT CONTAINER**

Ensure paint container is as clean as possible.

### **RECYCLE STEEL CONTAINER**

- The cleaned paint container can be disposed of via local steel recycling programs (check with your local Council).